EXTRACTING IN-WALL SPEAKERS

Removing any one of the **ci30**, **ci45**, **ci90slim**, and **ci65** models when they are mounted 'in-wall' is easy. Engage the two prongs of the **Qikfire**™ removal tool into the holes of the mounting mechanism and push until you feel the resistance of the spring. Then, push the tool until both prongs are fully engaged and turn toward the unlock position on the front baffle. This will reset the mechanism, and it will be ready for reinstallation.

Please heed all safety warnings (see pages 10 & 11)
NB: Forcing the **Qikfire** more than a quarter turn will damage the product

1.



Remove grille

2.



Use **Qikfire**™ removal tool to start extraction process

3.



Locate toggle holes, push in **Qikfire** removal tool, and turn anti-clockwise until the arrow lines up with the open padlock icon

4.



Repeat step 3

5.



Repeat step 3

6.



Repeat step 3

7.



Repeat step 3

8.



Your speaker can now be safely removed from the wall